

cook
prep
eat

USE & CARE

GLASS-SNAP
airtight food container



USE AND CARE

KEEP THIS MANUAL FOR FUTURE REFERENCE

BEFORE FIRST USE:

Wash thoroughly with a mild detergent, rinse & dry. Silicone gasket ejection may happen the first few times of use. This is normal & is not a defect.

CLEANING:

Top rack dishwasher safe. Do not use abrasive soaps or pads. You may remove the silicone gasket for cleaning. Be gentle when removing the gasket, do not use sharp objects. Store opened & thoroughly dry. Storing closed or while moist may grow mold.

CAUTION:

Do not place over open fire. Do not overfill. If freezing, do not fill over 70%. Glass & contents will be hot after microwave or oven use. Always use protective gear. Glass (and silicone sleeve if included) are freezer safe down to 5F and oven safe up to 500F. The lid is not oven safe. Do not lock lid while microwaving. Frequent & strong impact may cause breakage. Do not place directly from Freezer to oven or microwave. Extreme temperature changes can cause glass to break. All glass has the possibility of breakage & shattering, please be aware of this risk before use. If glass breaks, use protective gear to dispose properly. Never pick up broken glass with bare hands.

SAFE FOR



*WARNING: Glass container and silicone sleeve is oven safe.
Plastic lid is NOT oven safe



USE AND CARE

KEEP THIS MANUAL FOR FUTURE REFERENCE

ANTES DEL PRIMER USO:

Lave a fondo con un detergente suave, enjuague y seque. La expulsión de la junta de silicona puede ocurrir al comenzar su uso. Esto es normal y no es un defecto del fabricante.

LIMPIEZA:

Apto para lavavajillas en el rack superior. No utilizar esponjas o jabones abrasivos. Es posible quitar la junta de silicona para la limpieza. Cuidado al retirar la junta, no utilice objetos filosos. Guarde abierto y solo una vez completamente seco. Guardarlo cerrado o húmedo puede provocar moho.

PRECAUCIÓN:

No coloque sobre el fuego. Nunca llene en exceso. Si congela, no llene más del 70%. El vidrio y contenido estarán calientes después de su uso en horno o microondas. Utilice siempre protección. La tapa NO ES APTA PARA EL HORNO. El vidrio y el protector de silicona (si está incluido con este modelo) resiste temperaturas de -15 C a 260C. No cierre la tapa cuando la utilice en el microondas. Impactos frecuentes o fuertes pueden provocar la rotura del vidrio. No coloque directamente del congelador al horno o al microondas. Cambios bruscos de temperatura pueden provocar la ruptura del vidrio. El vidrio podría romperse, por favor, sea consciente de este riesgo antes de cualquier tipo de uso. Si el vidrio se rompe, use equipo de protección para desechar adecuadamente. Nunca recoja vidrios rotos con las manos desnudas.

SAFE FOR



DISHWASHER



OVEN



MICROWAVE



FREEZER

*WARNING: Glass container and silicone sleeve is oven safe.
Plastic lid is NOT oven safe



cook
prep
eat

GLASS-SNAP

airtight food container

FEATURES YOU NEED

- Leakproof silicone gasket
- Stackable for easy storage
- Long lasting lid clips



**SILICONE
PROTECTION**
PROTECCIÓN DE
SILICONA



**LEAK-PROOF
LID**
TAPA A PRUEBA DE
FUGAS

